


راهنمای تنظیمات مودم Linksys

جهت انجام تنظیمات مورد نیاز و وارد کردن مشخصات سرویس اینترنت لازم است که به کنسول مودم متصل شوید.

(۱) یک صفحه مرورگر باز کنید و IP پیش فرض مودم را در Address Bar جستجو کنید: ۱۹۲،۱۶۸،۱،۱



(۲) User و Password ورود به تنظیمات مودم را admin وارد کنید:



(۳) پس از وارد کردن User و Password صفحه اصلی تنظیمات مودم به صورت زیر نمایش داده می شود؛ گزینه Setup را انتخاب کنید، از قسمت Basic Setup بخش Internet Connection Type را روی حالت PPPoE قرار دهید، مقادیر VPI:0 و VCI:35 را در فیلدهای مربوطه وارد کنید، User و Password که شرکت های وب در اختیار شما قرار داده را در کادر مربوطه وارد کنید:

The screenshot shows the Cisco Linksys X2000 web interface. The top header includes the Cisco logo and the text "Firmware Version: v2.0.01". The navigation menu on the left includes "Setup", "Language", "Internet Setup", "PPPoE Settings", and "Optional Settings (required by some Internet Service Providers)". The main content area is titled "Internet Setup" and contains the following settings:

- Language: English
- Internet Connection Type: RFC 2516 PPPoE
- Multiplexing: LLC (selected), VC
- QoS Type: UBR
- PCR: 4000 cps
- SCR: 4000 cps
- Autodetect: Disable (selected), Enable
- Virtual Circuit: 0 VPI (Range 0-255), 35 VCI (Range 0-65535)
- DSL Modulation: MultiMode
- User Name: نام کاربری
- Password: *****
- Service Name(optional):
- Connect on Demand - Max Idle Time: 5 Minutes
- Keep Alive - Redial Period: 30 Seconds
- Host Name:
- Domain Name:
- MTU: Auto, Size: 1492

سپس در انتهای صفحه روی گزینه Save Settings کلیک کنید.

Optional Settings (required by some Internet Service Providers)	Host Name: <input type="text"/>
	Domain Name: <input type="text"/>
	MTU: <input type="text" value="Auto"/> Size: <input type="text" value="1492"/>
Network Setup	
Router Address	IP Address: <input type="text" value="192"/> . <input type="text" value="168"/> . <input type="text" value="1"/> . <input type="text" value="1"/>
	Subnet Mask: <input type="text" value="255.255.255.0"/>
	Device Name: <input type="text" value="Cisco18317"/>
DHCP Server Setting	DHCP Server: <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled <input type="radio"/> DHCP Relay
	DHCP Relay Server: <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>
	<input type="button" value="DHCP Reservation"/>
	Start IP Address: <input type="text" value="192.168.1.100"/>
	Maximum Number of Users: <input type="text" value="50"/>
	IP Address Range: <input type="text" value="192.168.1.100"/> to <input type="text" value="149"/>
	Client Lease Time: <input type="text" value="0"/> minutes (0 means one day)
	Static DNS 1: <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>
	Static DNS 2: <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>
	Static DNS 3: <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>
	WINS: <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>
Time Settings	
Time Zone	<input type="text" value="(GMT-08:00) Pacific Time (USA & Canada)"/>
	<input type="checkbox"/> Automatically adjust clock for daylight saving changes.
Reboot	
	<input type="button" value="Reboot"/>
	<input type="button" value="Save Settings"/> <input type="button" value="Cancel Changes"/>

های وب HiWEB

۴) به منظور انجام تنظیمات Wireless گزینه Wireless را انتخاب کنید:

The screenshot shows the Cisco Linksys X2000 web interface. At the top left is the Cisco logo. The top right corner displays 'Firmware Version: v2.0.01'. Below the logo is a navigation menu with 'Wireless' selected. Under 'Wireless', there are sub-menus: 'Setup', 'Wireless', 'Security', 'Access Policy', 'Applications & Gaming', 'Administration', and 'Status'. The 'Wireless' sub-menu is further divided into 'Basic Wireless Settings', 'Wireless Security', 'Guest Access', and 'Wireless MAC Filter'. The main content area is titled 'Wi-Fi Protected Setup' and contains two radio buttons: 'Manual' and 'Wi-Fi Protected Setup™', with the latter selected. Below this, the text reads: 'Use one of following for each Wi-Fi Protected Setup™ supported device:'. There are three numbered instructions: 1. 'If your client device has a Wi-Fi Protected Setup™ button, click or press that button and then click the button on the right.' accompanied by a circular arrow icon. 2. 'If your client device has a Wi-Fi Protected Setup™ PIN number, enter that number here [input field] and then click: [Register button]'. 3. 'If your client asks for the Router's PIN number, enter this number 86720205 in your client device.' At the bottom, the current network settings are displayed: 'Network Name (SSID): Cisco18317' and 'Security: Disabled'. A 'Help...' link is visible on the right side of the page.

های وب HiWEB

۵) به منظور تغییر نام Wireless از قسمت Basic Wireless Settings گزینه Manual را انتخاب کنید؛ در قسمت SSID نامی را برای شبکه بیسیم خود برگزینید.

The screenshot shows the Cisco HiWEB configuration page for a Linksys X2000 router. The interface is in Persian. At the top, the Cisco logo is on the left and the firmware version 'v2.0.01' is on the right. Below the logo, the 'Wireless' section is active, with sub-tabs for 'Setup', 'Wireless', 'Security', 'Access Policy', 'Applications & Gaming', 'Administration', and 'Status'. The 'Wireless' sub-tab is selected, showing 'Basic Wireless Settings'. The configuration options are as follows:

- Radio Mode: Manual Wi-Fi Protected Setup™
- Network Mode:
- Network Name (SSID):
- Channel Width:
- Standard Channel:
- SSID Broadcast: Enabled Disabled

At the bottom of the configuration area, there are two buttons: 'Save Settings' and 'Cancel Changes'. A 'Help...' link is visible on the right side of the page.

های وب HiWEB

۶) مودم به صورت پیش فرض کلمه عبوری جهت استفاده از Wireless ندارد و میبایست جهت محافظت از سرویس خود و جلوگیری از ورود و استفاده افراد غیر مجاز از قسمت Wireless Security از لیست موجود یکی از انواع سیستم های رمز گذاری وایرلس را انتخاب کنید، آنرا به WPA2/WPA Mixed mode تغییر دهید، سپس در قسمت Passphrase یک رمز بین ۸ تا ۶۳ کارکتری وارد کنید سپس روی گزینه Save Settings کلیک کنید :

